











			
005	205	012	0103
			
0104	199	233	797
			
112	031	011	638
			
46	1010	156	667
			
579	36	677	59
			
064	034	717	213
			
212	700	51	310
			
30D	100	901	751
			
115	113	114	2/19 (valkea/musta)
			
28 (valkea/hopea)	302	300	301
			
303	9406	9401	9405
		Näytöllä näkyvät värit on tuotettu sähköisesti ja ne eivät välttämättä vastaa aitoa väriä johtuen näytön asetuksista ja kiiltoasteista. Valitse aina lopullinen väri jälleenmyyjillä näytillä olevista värimalleista.	
9403	9402		